

Product Overview

HOKUYO SAFETY LASER SCANNER



HOKUYO



SCHMERSAL
THE DNA OF SAFETY

OVERVIEW

Compact and user friendly

Compact design for installation on AGVs and AGCs, as well as in safety guarding applications.

Size: 95 x 80 x 80 mm
3.75 x 3.15 x 3.15 inches

Weight: 0.5 kg

Conformity to standards:



IEC61469-1/3	Type 3
IEC61508	SIL2
ISO13849-1	PLd Category 3
UL508	
UL1998	
UL61496-1	Type 3
CSA C22.2	No. 14



Easy configuration of complicated zones


User friendly interface

Simple user interface to configure even a complicated zone by simultaneously viewing the measurement data. Zones can be configured with 3 different methods




Applications

Collision protection




32 safety area patterns to accommodate the AGV travel path for collision protection

Presence detection



Detects humans or objects entering the hazardous area.

Intrusion detection



Detects access into critical zone at point of operation.

FEATURES


Protection over a wide range

Up to 5 meters of protection zone and 20 meters of warning zone configuration to suit various application requirements.



Data output via Ethernet

Measurement data can be acquired via Ethernet, with status of input/output signals and cyclic redundancy check code. Also supports command in SCIP2.0 protocol.



SD card for configuration


Configuration data can be saved to a SD card, which in turn can be used for configuring the UAM without connecting a PC. The Feature is useful while replacing the UAM or configuring multiple units with the same settings.



Master-Slave function


Up to 4 units can be interconnected for Master-Slave operation when multiple units are required to guard the hazardous area. The system can be controlled by connecting the input and output signals to Master unit only.

Important note: It is not possible to control actuators via master-slave bus communication.




Encoder input

In AGV applications, area is switched depending on the vehicle's speed. Speed and direction of travel provided via encoders are constantly monitored to switch the area and stop the AGV during abnormal travel.



Dual protection mode

The scanner can simultaneously protect two adjacent hazardous areas. Separate OSSD signals are triggered for the respective protection zones making it possible to guard two machines with a single scanner unit.



SYSTEM COMPONENTS

Main unit



Model number	Description
UAM-05LP-T301	Scanner, 3m cable with flying leads, software included
UAM-05LP-T301C	Scanner, 300mm cable with connector, software included

Extension cable without connector (For T301 model)



Model number	Description
UAM-5C10	Cable length: 10 m
UAM-5C20	Cable length: 20 m

Extension cable with connector (For T301C model)



Model number	Description
UAM-5C02C	Cable length: 2 m
UAM-5C05C	Cable length: 5 m
UAM-5C10C	Cable length: 10 m
UAM-5C20C	Cable length: 20 m

Brackets and Accessories



Model number	Description
UAM-BK03	Base mounting bracket
UAM-BK04	Rear mounting bracket
UAM-BK05	Cover bracket (protect the optical window)
UAM-W002	Replacement optical window (lens)
UAM-ENET	Ethernet cable, Length: 3 m

SPECIFICATIONS


Detection property	Protection range	Max: 5 m	
	Warning range	Max: 20 m (non-safety) * ¹	
	Distance tolerance * ²	+100 mm	
	Direction capability	From black-reflector sheet (1.8%) to retro-reflector sheet	
	Detection angle	270°	
	Minimum width / detectable distance	Ø 30 mm, max: 1.8 m Ø 50 mm, max: 3.0 m Ø 70 mm, max: 5.0 m	
	Scan frequency	30 ms (rotational speed 2000 rpm)	
	Area pattern	Max 32 patterns for safety and 64 patterns for non-safety	
	Response time	OFF 60 ms ~ 510 ms / ON 270 ms ~ 510 ms	
Optics	Element	Pulsed laser diode	
	Wave length	905 nm	
	Safety Class	Laser class 1	
Type	Type 3 (IEC 61496-1, IEC 61496-3)		
Functional Safety	SIL2 (Type B, HFT=1) (IEC 61508)		
PFH _d	7.8x10 ⁻⁸ (T1=20 year): When master-slave function not in use 1.6x10 ⁻⁷ (T1=20 year): When master-slave function in use		
Housing	Size	80.0 mm (W), 80.0 mm (D), 95.0 mm (H), without cable	
	Weight	0.5 kg	
	Protection	IP65	
	Case material	Body: Aluminium, Optical window: polycarbonate	
	Connection cable	T301: Flying lead cable: 3 m T301C: Cable with IP67 connector, cable 0.3 m	
Power Supply	DC 24 V ±10% when using converter power supply DC 24 V -30%/+20% when using battery		
Supply current	Normal (without load)	6 W	
	Max. (with load)	50 W	
Output	OSSD 1/2 (Safety)	Output type: high side SW Leak current: Max 1 mA Load tolerance: L/R = 25 ms, C=1µF	Output current: Max 500 mA * ³ AWG 26
	OSSD 3/4 (Safety) WARNING 1/2 (non-safety)	Output type: high side SW Leak current: Max 1 mA Load tolerance: L/R = 25 ms, C=1µF	Output current: Max 250 mA * ³ AWG 28
	RES_REQ 1, RES_REQ 2 MUT_OUT 1, MUT_OUT 2	Output type: PNP Transistor Leak current: Max 1 mA	Output current: max 200 mA * ³ AWG 28
Input	Input impedance 4.7 kΩ		AWG28
Interface	Configuration	USB2.0 (USB micro type-B connector)	
	Data output	Ethernet 100BASE-TX (waterproof connector)	
Environmental resistance	Temperature	-10°C to +50°C (no freezing)	Storage: -25°C to +70°C (no freezing)
	Humidity	95% RH with no condensation	Storage: 95% RH with no condensation
	Surrounding intensity * ⁴	Less than 1500 lx	
	Vibration	Frequency range: 10~55 Hz	Sweep rate: 1 octave/min
Bump	Acceleration: 98 m/s ² (10G)		Pulse duration: 16 ms
Outdoor operation	Not permitted		
Altitude	Below 2000 m		

*¹ Distance when reflectance of the object is 90% or above.

*² Additional distance of 200 mm is needed when UAM is working under high reflective background.

*³ Total current supply of OSSD output and Warning output should be below 1.0A.

*⁴ When the light sources are located at ≥5° from the detection plane of UAM.




R1 and R2 : External equipment (Safety relay, Electromagnetic contactor)
S1: Interlock reset switch

*1: Refer to user's manual for details on area switching.


Color	Signal	Function	Description	AWG
Brown	+24V DC	Power	Power Supply DC 24V	22
Blue	0V DC	Power	Power Supply DC 0V	22
Red	OSSD1	Output	Protection zone output 1	26
Yellow	OSSD2	Output	Protection zone output 2	26
Red/Black	OSSD3 WARNING1	Output	Protection zone output 3 Warning zone output 1	28
Yellow/Black	OSSD4 WARNING2	Output	Protection zone output 4 Warning zone output 2	28
Purple	IN_A	Input	Area switching input A	28
Gray	IN_B MUTING3	Input	Area switching input B Muting input 3	28
White	IN_C OVERRIDE1 ENC1_A	Input	Area switching input C Override input 1 Encoder input 1_A	28
Pink	IN_D MUTING1 ENC1_B	Input	Area switching input D Muting input 1 Encoder input 1_B	28
Green	IN_E EDM1	Input	Area switching input E External device monitoring 1	28
Purple/Black	IN_A	Input	Area switching input A invert	28
Gray/Black	IN_B MUTING4	Input	Area switching input B invert Muting input 4	28
White/Black	IN_C OVERRIDE2 ENC2_A	Input	Area switching input C invert Override input 2 Encoder input 2_A	28
Pink/Black	IN_D MUTING2 ENC2_B	Input	Area switching input D invert Muting input 2 Encoder input 2_B	28
Green/Black	IN_E EDM2	Input	Area switching input E invert External device monitoring 2	28
Yellow/Green	RESET1	Input	Reset input 1	28
Yellow/Blue	RESET2	Input	Reset input 2	28
Orange	RES_REQ1 MUT_OUT1	Output	Request output 1 Muting state output 1	28
Orange/Black	RES_REQ2 MUT_OUT2	Output	Request output 2 Muting state output 2	28
White/Blue (TP)	RS485+	Comm	Communication protocol RS485	28
White/Red (TP)	RS485-	Comm	Communication protocol RS485	28
Shield wire	FG	--	Frame ground	--

Input / Output circuit


OSSD output circuit
OSSD/Warning output is output type.



Other Output circuit
RES_REQ1, RES_REQ2, MUT_OUT1,
MUT_OUT2 output circuit.




Input circuit
Area input, EDM1, EDM2, RESET1,
RESET2, MUTING1, MUTING2,
MUTING3, MUTING4, OVERRIDE1,
and OVERRIDE2




DIAGRAMS


UAM-05LP-T301




UAM-05LP-T301C



Rear mounting bracket with Cover bracket



Base mounting bracket with Cover bracket



tec.nicum

Schmersal Group

Functional machine safety is a complex matter which involves complying with a range of standards and directives. tec.nicum offers all machine manufacturers, operators and distributors a completely product and manufacturer-neutral consultancy on all currently relevant statutory regulations and supports them in ensuring their machines and workplaces are designed to comply with the relevant standards.

Experts at tec.nicum advise and support customers and clients with training, on-site consultation, documentation and planning and implementation, such as the installation of protective equipment and safety systems.

tec.nicum is the Schmersal Group's service division and comprises a global consultancy network of TÜV Rheinland-certified Functional Safety Engineers and Machinery CE Experts. Services can be called upon around the world. tec.nicum's core philosophy is to offer advice that is independent of manufacturers and as objective as possible.

We strive to develop the best possible safety-related solution for each individual application, to implement it and completely safeguard its intended use – always in line with our commitment **“excellence in safety – we care!”**

tec.nicum services cover four areas, which can be obtained as individual modules or as complete packages:

academy



- Seminars and training
- In-house training
- Customer-specific workshops
- Demonstration events
- Symposia

consulting



- Safety analysis of machines and production lines
- Conformity assessment and verification
- Risk assessments
- Hazard assessments
- Technical documentation

engineering



- Technical project planning
- Validation of safety functions
- Measurements and tests
- Modernisation of machines
- Safety controller programming

integration



- Conversion / Retrofitting
- Installation of protective devices and fences
- Integration of safety functions
- Maintenance and service

SCHMERSAL USA

15 Skyline Drive, Hawthorne, NY 10532
Tel: 914-347-4775 / Fax: 914-347-1567
E-mail: salesusa@schmersal.com
www.schmersalusa.com

SCHMERSAL CANADA

29 Centennial Road, Unit 1, Orangeville, ON L9W 1R1
Tel: 519-307-7540 / Fax: 519-307-4775
E-mail: salescanada@schmersal.com
www.schmersalcanada.ca